“L” Heater Fence Assembly Manual

IMPORTANT SAFETY INSTRUCTIONS

DANGER: Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

WARNING: Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

CAUTION: Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

NOTICE: Indicates information considered important, but not hazard-related.

FOLLOW SAFETY INFORMATION IN THIS DOCUMENT TO AVOID SERIOUS INJURY OR DEATH

REFER TO YOUR LOCAL BUILDING CODES FOR ANY SPECIFIC INSTALLATION REQUIREMENTS

ALL ELECTRICAL WORK NEEDS TO BE COMPLETED BY A LICENSED ELECTRICIAN. FAILURE TO DO SO COULD CAUSE INJURY OR DAMAGE TO THE HEATER.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

REFERENCE SAUNA AND/OR HEATER MANUALS FOR FURTHER SAFETY INFORMATION

Heater Fence Assembly

⚠ CAUTION

• Do not install the heater fence while the heater is running or hot. The outside of the heater is very hot and will cause burns if touched.


Step 1: The heater fence kit will come banded in stretch wrap, remove the wrap and place the two pieces on your working surface. Match the two pieces as shown below.







Step 2: Turn over matched pieces so the long section is face down. Ensure the boards are flush in the top corner for optimal fitment. Attach the two pieces together using the two predrilled holes and remaining screws from your sauna hardware kit. It is recommended to keep pressure on the two square boards during fastening for easier assembly.


Step 3: To install heater fence into sauna, use the four predrilled holes and screws from sauna hardware kit. Place fence around heater and fasten into side and front wall panels.





For technical assistance, please call 877-842-7842 or email us at support@harvia.us.