
SaunaMax Pro Instruction Manual



Power on/off

Press MODE to control the output of the light. There are 3 modes that run in a circle (Red mode, NIR mode, and Combined mode).

When the R+ indicator illuminates, it means that you chose the Red mode.

When the NIR+ indicator illuminates, it means that you chose the NIR mode.

When both R+ NIR+ indicators illuminate, it means that you chose the Combined mode.

Press MODE button for at least 3s, to switch between the SOLO mode and Remote mode. When the indicator illuminates, it means that you chose the Remote mode.

Press MODE and use the "+" and "-" keys to select the intensity of your lights. Once desired intensity is set, the intesity you selected will stay in memory and the light will default to this when started.

Press TIME and use the "+" and "-" keys to select the amount of time you want your session to be. Once set, the time you selected will stay in memory and the light will default to this when started. The maximum time is 30 minutes.

Press both "+" and "-" button for at least 3s to toggle silent mode. Audible mode is by default. Once you changed the mode, it will stay in memory and light will default to this when started next time. When the indicator illuminates, it means that you chose the silent mode.

Press BLUE button to turn on /off the blue lights. When the B+ indicator illuminates, it means that you have turned on the blue lights. If you only want to use the blue lights, press "-" button till the intensity for the Red and NIR is set to zero, then press the blue mode button. (Note: The intensity of blue lights can't be adjusted.)

Press OK button to begin or pause your session at any time.

1.Remember that near infrared LEDs emit light that is NOT visible to the naked eye.

2.When circle LED strip light flickers, it means that the light is in the setting process, please press OK button to start your session, then OK button will illuminate.

Remote Control

Battery indicator (When it flashes that means the battery is running low, it needs to be charged. When it is fully charged, this indicator will keep illuminating. When you charge the remote control, this indicator will flicker in respiratory rate.)

ON button: Press ON button to turn on the light. Combo mode, 100% intensity and 20 minutes for a session are the default settings when you use the remote control.
Note:
1. The remote control can't turn on or turn off the blue lights separately. The blue lights can be turned on/off using the BLUE button on the light. Once set, this will stay in memory and the light will default to this when started.
2. The remote control can only turn on, turn off, and pause the sessions. There is no way to adjust the intensity or time using the remote control.



Signal indicator(It will flash when you press the buttons.)

Digital Link Cable port

OFF button: Press OFF to pause the session when you need a break, and press OFF again to continue, the light will continue to count down. Press OFF button and hold on at least 5s to turn off the light. If the light is turned off, press ON button to start a new session.

Charging port

Notes:

1. Make sure the light enters the Remote mode (Remote mode indicator illuminates) when you want to use the remote control in the session.
2. The remote control only can turn on, turn off and pause the sessions, you can't adjust the intensity or time.
3. The remote won't keep sending signal to the light, only when you press the buttons, it will send the signal, and the light will run according to your operation.

PlatinumLED Total Control System

Download the free smartphone application for wireless control of your SaunaMax!



Available on the App Store

GET IT ON Google Play


Please press MODE button at least 3s to enter Remote mode when you want to use the APP to control your light, the indicator will illuminate when you enter the Remote mode.
Make sure your phone's Bluetooth device is turned on.

Door hook installation instruction

1

Get Ready


Lay your PlatinumLED light and all of the included hardware out on a padded surface.



2

Attach Hanging Hardware

Screw the threaded posts into the top of your light. Next, screw the cable supports to the top of the threaded posts.




Door hook installation instruction

3

Attach Door Hook(s)

Hang the door hook on the top of any standard-sized door.




4

Connect Hanging Cables

Connect cable supports to the snaplink. Then, hang the other end of the cable assembly directly on the door hook.


To raise the height of your SaunaMax Pro, pull down on the height adjustment cable while supporting the bottom of your light with your other hand.

To lower your light, press the lever on the cable box.




Sauna room door installation instruction


1




2



3



4



5

